

Clamp Instructions

All RPM Steering clamps are 6 or 8 bolt clamps. DO NOT use a mini-impact or drill to start the threads on the stainless screw clamps. All threads are tested at final assembly. Hand thread the screws with an Allen key at least 3-5 turns before using any power tools on them.

For best clamping power snug and set spacing with the center two screws, then use a crisscross pattern on the corners at $\frac{1}{4}$ turn only until hand tight.

Standard Stabilizer Clamp

- 1) Install the $\frac{1}{2}$ -20 x2" bolt through the eye on the stabilizer.
- 2) Test fit the bolt to determine if the supplied washers are needed to keep the threads from protruding inside the clamp.
- 3) Use blue lock tight to thread the bolt into the clamp.



STANDARD VERSION



FOX ATS VERSION

Falcon Clamp

- 1) Remove factory Falcon clamp.
- 2) Slide provided WASHERS over Falcon threads.
- 3) Thread Falcon into RPM clamp using blue lock tight.
- 4) DO NOT Torque – just hand tighten



FALCON VERSION