



JL/JT Ultimate Trackbar Instructions

1. With Jeep on level ground remove factory trackbar and hardware.
2. Using the suggested length chart below, set all joints. (Note that on the double adjustable trackbars you must equally thread out and in each joint end.

Suggested lengths:

Front	JL Rear w/Bracket	JT Rear w/Bracket
2.5" Lift 34 3/16"	2.5" Lift 37 9/16"	2.5" Lift 33 5/16"
3.5" Lift 34 5/16"	3.5" Lift 37 11/16"	3.5" Lift 33 9/16"
4.5" Lift 34 7/16"	4.5" Lift 37 13/16"	4.5" Lift 33 11/16"
5.5" Lift 34 1/2"	5.5" Lift 37 7/8"	5.5" Lift 33 7/8"

Warranty:

Center aluminum section is lifetime warrantied for failure, including bending, cracking, or breaking. Should any of these failures occur please send the center section to RPMSTEERING for replacement. (Shipping and handling additional).

Disclaimer:

Customer assumes full responsibility for use, installation and routine maintenance. RPM Steering is not responsible for damage as a result of improper installation, use or maintenance.